



1139 BAKER ST.  
COSTA MESA, CA 92626  
(714) 549 3041  
FAX (714) 549 0930

A Components Corporation of America Company

**TECHNICAL BULLETIN TB-156**

**STACOSWITCH DATA ENTRY PRODUCTS  
CHEMICAL COMPATIBILITY LIST**

The StacoSwitch Data Entry Products are designed to be compatible with most chemical solutions. The Data Entry Product parts such as keycaps, keypads, and enclosures have been tested with the chemical solutions listed below. The user may rinse the sealed section of the Data Entry Product with distilled water and patted dry with a soft cloth.

**Data Entry Parts Compatibility List**

Data Entry Part	Solution/ Concentration	Method of Exposure	Duration of Test	Effect
Keycap	Pure Ammonia	Immersed	2 hours	None
Keycap	Window Cleaner (Windex)	Immersed	2 hours	None
Keycap	Coffee	Immersed	2 hours	None
Keycap	Coca-Cola, Non-diet	Immersed	2 hours	None
Keycap	Beer (Pabst)	Immersed	2 hours	None
Keycap	10% Bleach	Rubbed	1 hour	None
Keypad				
Enclosure				
Keycap	Betadine (10% povidine-iodine)	Rubbed	1 hour	None
Keypad				
Enclosure				
Keycap	Aguasonic gel (Spectra 360)	Rubbed	1 hour	None
Keypad				
Enclosure				
Keycap	Cidex (3.4% Glutaraldehyde)	Immersed face down in 4.55 mm deep Cidex	20 minutes	None
Keypad				
Enclosure				

If required, contact StacoSwitch for detail test results and other solutions.

Rev.	Rel. ER	Date
NC	02-37585	4-10-01

Sheet	of
1	1