

**STACOSWITCH DATA ENTRY PRODUCTS  
CHEMICAL COMPATIBILITY LIST**

The StacoSwitch Data Entry Products are designed to be compatible with most chemical solutions. The Data Entry Product parts such as keycaps, keypads, and enclosures have been tested with the chemical solutions listed below. The user may rinse the sealed section of the Data Entry Product with distilled water and patted dry with a soft cloth.

**Data Entry Parts Compatibility List**

| Data Entry Part | Solution/<br>Concentration        | Method of<br>Exposure                          | Duration<br>of Test | Effect |
|-----------------|-----------------------------------|--|---------------------|--------|
| Keycap          | Pure Ammonia                      | Immersed                                       | 2 hours             | None   |
| Keycap          | Window Cleaner (Windex)           | Immersed                                       | 2 hours             | None   |
| Keycap          | Coffee                            | Immersed                                       | 2 hours             | None   |
| Keycap          | Coca-Cola, Non-diet               | Immersed                                       | 2 hours             | None   |
| Keycap          | Beer (Pabst)                      | Immersed                                       | 2 hours             | None   |
| Keycap          | 10% Bleach                        | Rubbed   | 1 hour              | None   |
| Keypad          |                                   |  |                     |        |
| Enclosure       |                                   |  |                     |        |
| Keycap          | Betadine<br>(10% povidine-iodine) | Rubbed   | 1 hour              | None   |
| Keypad          |                                   |  |                     |        |
| Enclosure       |                                   |  |                     |        |
| Keycap          | Aguasonic gel<br>(Spectra 360)    | Rubbed   | 1 hour              | None   |
| Keypad          |                                   |  |                     |        |
| Enclosure       |                                   |  |                     |        |
| Keycap          | Cidex<br>(3.4% Glutaraldehyde)    | Immersed face<br>down in 4.55 mm<br>deep Cidex | 20 minutes          | None   |
| Keypad          |                                   |  |                     |        |
| Enclosure       |                                   |  |                     |        |

If required, contact StacoSwitch for detail test results and other solutions.

|      |          |      |
|------|----------|------|
| Rev. | Rel. ER  | Date |
| NC   | 02-37585 |      |

|       |    |
|-------|----|
| Sheet | of |
| 1     | 1  |